



SAMPLE FLOOR PLAN

58" TO CENTER OF VENT, 66" OFF FLR.

PLUMBING- MAKE SURE ALL PLUMBING AND ELECTRICAL ARE INSIDE SINK CABINET

HELPFUL HINTS

- Know all of your appliance sizes before you start.
- Allow space from side of cabinets to wall (fillers) so drawers don't hit jams or wall.
- Inside corners should be large enough (fillers) to let drawers open without hitting anything.
- In most cases appliances can be moved several inches to accommodate the new layout.